

# Starting the new U-CAR Prius



1. Hold the silver button of the yellow wand (Key FOB) on the “*Data Key Reader*” (*Black box under dash*), for about one second, until the green light starts flashing. You have one minute to start the car. If you take longer, the flashing green light turns to red again and you need to repeat this process.



2. Insert key (Black remote) into the designated area between steering wheel and gear shifter
3. Depress the brake pedal and press “Power” button at the same time (If you depress the power button before the brake pedal, the vehicle will not start).
4. Put the vehicle in gear and you’re ready to go!